





## Aufbauanleitung Halfmoon Banner

## Assembly Instructions Halfmoon Banner



Halfmoon Banner sind für den mobilen, nicht dauerhaften Einsatz bestimmt. Im Außenbereich sollte der Einsatz nur unter Aufsicht erfolgen.

### Lieferumfang

- 2 Werbedrucke (optional)
- 4 Endstangen mit Karabinerhaken auf einer Seite
- 2 Mittelstangen ohne Karabinerhaken
- 4 Erdhaken zur Verankerung im Außenbereich
- 1 Tasche für Erdhaken
- 1 Transporttasche

### Aufbau

- 1 Nehmen Sie die Teile aus der Transporttasche und legen Sie diese auf eine saubere und flache Oberfläche.
- 2 Verbinden Sie eine Endstange mit einer Mittelstange und führen Sie diese vorsichtig durch den Hohlraum an der Oberkante des Werbedrucks.
- 3 Anschließend verbinden Sie diese mit einer weiteren Endstange.
- 4 Wiederholen Sie die Schritte 2 und 3 an der anderen Seite des Bannersystems.
- 5 Befestigen Sie die Gurtbandschlaufen an jeder Seite des Werbedrucks am Karabinerhaken der Endstangen.
- 6 Stellen Sie beide Werbedrucke auf die Längsseiten und verbinden Sie die an der Oberkante jeweils gegenüberliegenden Klettbinden miteinander.  
**Achtung:** Die richtige Positionierung der Grafiken beachten.
- 7 Zum Schluss schließen Sie die seitlichen Klettbinden.
- 8 **Für den Außengebrauch:** Stecken Sie die Erdhaken jeweils durch den Metalring am Ende jeder Stange und schlagen Sie ihn in das Erdreich ein.

The Halfmoon Banner is made for the short-term use and not for permanent installation. An outdoor usage should be supervised.

### Scope of delivery

- 2 prints (optional)
- 4 end poles with snap hooks on one side
- 2 center poles without snap hooks
- 4 earth hooks for outdoor use
- 1 bag for earth hooks
- 1 transport bag

### Assembling

- 1 Begin by removing the parts from the transport bag and place them on a clean flat surface.
- 2 Connect one end pole with one center pole and place them carefully through the sleeve on the upper edge of the print.
- 3 Then connect it to a further end pole.
- 4 Repeat the steps 2 and 3 with the other side of the banner system.
- 5 Attach the webbing loops on each side of the print to snap hooks of the end poles.
- 6 Place both advertising prints on the longitudinal side and connect them by attaching the hook-and-loop bands which are located opposite of each other on the top.  
**Caution:** Observe correct positioning of the print.
- 7 Lastly close the side Velcro straps.
- 8 **For outdoor use:** Place the ground spikes into the metal ring at the end of each pole and fix them to ground.